

INSTRUCTIONS



How to use haid-tec MelaminPlusPad®

MelaminPlusPads can be used by hand or with machines.

Please keep to the following guidelines:

- **Do not use** haid-tec MelaminPlusPads **dry!**
- The grey-white melamine foam pad should be directed towards the flooring.
- Use only cleaning machines that meet the latest technical standards, with a high-power drive motor and sufficient battery capacity.
- **Do not use** on sensitive surfaces (e. g. high-gloss plastics, varnished surfaces etc.).
- Test on an inconspicuous area before use (follow floor manufacturer's instructions)

Fix haid-tec MelaminPlusPads to a pad holder appropriate for use on the machine:

- **Single-disc machines** - use MelaminPlusPads with strong scouring fleece backing, suitable with all common pad drivers (hooks, velcro, rubber knobs, etc.)
- **Scrubbing machines** - we recommend using an inner hole mount
- **Orbital machines** - use MelaminPlusPads with Velcro backing
- **Excenter machines** - use MelaminPlusPads with Velcro backing
- **Single-disc machines** - use MelaminPlusPads

The pad's extremely high cleaning capacity means that the quantity of cleaning agent used can be reduced in some cases. Pads can be used with all standard cleaning agents (follow manufacturers' instructions on usage and dosage).

The Pads wear down during cleaning. When the grey-white melamine foam is worn down, new pads have to be attached.

Unlike conventional melamine pads, haid-tec MelaminPlusPads have a very long product lifetime that is dependent on the floor surface, quality of floor installation and type of cleaning machine used.

