

INSTRUCTIONS

How to use haid-tec MelaminPlusPad®



MelaminPlusPads can be used by hand or with machines.

Please keep to the following guidelines:

- **Do not** use haid-tec MelaminPlusPads in a dry condition!
- The grey-white melamine foam pad should be directed towards the flooring.
- Use only cleaning machines that meet the latest technical standards, with a high-power drive motor and sufficient battery capacity.
- **Do not** use on sensitive surfaces (e. g. high-gloss plastics, varnished surfaces etc.).
- Test on an inconspicuous area before use (follow floor manufacturer's instructions)

Fix haid-tec MelaminPlusPads to a pad holder appropriate for use on the machine:

- **Scrubbing machines** - we recommend using an inner hole mount
- **Orbital-/Eccenter machines** - Use MelaminPlusPads OE with Velcro backing
- **Single-disc machines** - Use MelaminPlusPads basic

The pad's extremely high cleaning capacity means that the quantity of cleaning agent used can be reduced in some cases. Pads can be used with all standard cleaning agents (follow manufacturers' instructions on usage and dosage).

The Pads wear down during cleaning. When the grey-white melamine foam is worn down, new pads have to be attached.

Unlike conventional melamine pads, haid-tec MelaminPlusPads have a very long product life-time that is dependent on the floor surface, quality of floor installation and type of cleaning machine used.

