

Instructions

Use of haid-tec MonoMelaminPad



Consider the following when using MonoMelaminPads

- Do not apply haid-tec MonoMelaminPad dry!
- DO NOT use on sensitive surfaces (e.g., high-gloss plastics, painted surfaces, etc.).
- Test in an inconspicuous area before application if necessary (follow the floor manufacturer's recommendations)

Mount haid-tec MonoMelaminPads on suitable drive plates of the machine:

- **Single-disc machines** - Use MonoMelaminPads with a robust scrubbing fleece back for use with all common drive plates (hooks, velcro, rubber studs, etc.)

Due to their **excellent mechanical cleaning properties**, the use of cleaning agents may be reduced if necessary.

The pads are compatible with all common cleaning agents (follow manufacturer's instructions for application and dosage).