

# Instructions



## The use of haid-tec MelaminPlusPad

MelaminPlusPads can be used both manually and with a cleaning machine.

**The following points must be considered:**

- Do not apply haid-tec MelaminPlusPads dry!
- The gray-white melamine foam should face towards the floor covering.
- Unlike conventional melamine pads, also suitable for scrubber-dryers with weak motors and low battery capacity.
- Do not use on sensitive surfaces (e.g., high-gloss plastics, painted surfaces, etc.).
- Test in an inconspicuous area before application (follow the floor manufacturer's recommendations)

Mount **haid-tec MelaminPlusPads** on suitable drive plates of the machine:

- **Single-disc machines** - Use MelaminPlusPads with a robust scrubbing fleece back for use with all common drive plates (hooks, velcro, rubber studs, etc.)
- **Scrubber-dryers** - Use of an inner hole holder is recommended
- **Orbital machines** - Use MelaminPlusPads with velcro backing
- **Eccentric machines** - Use MelaminPlusPads with velcro backing

Due to their excellent mechanical cleaning properties, the use of cleaning agents may be reduced if necessary. The pads are compatible with all common cleaning agents (follow manufacturer's instructions for application and dosage).

In contrast to conventional melamine pads, haid-tec MelaminPlusPads have significantly longer durability, depending on the surface condition of the flooring, the quality of installation, and the type of cleaning machine used.



haid-tec  
geprüfte Oberflächentechnik GmbH  
Riedstraße 10  
D-89616 Rottenacker  
T: +49 7393 / 918 39 10  
F: +49 7393 / 918 39 19  
E: [info@haid-tec.de](mailto:info@haid-tec.de)  
[www.haid-tec.com](http://www.haid-tec.com)  
[shop.haid-tec.com/](http://shop.haid-tec.com/)